


# 5 COGO Menu



## 5.1 Point Traverse

**Point Traverse** is the main COGO application and is available in two modes, the *Standard* mode and the *Sideshot* mode. The two modes operate completely different. The *Standard* mode is more powerful while the *Sideshot* mode is in some ways simpler to learn/use.


### Standard Mode

**Point Traverse Standard** is a complete COGO solution with **Inverse** and **Intersections** built into the command line interface. Input screens within this application often take multiple types of input to allow a wide variety of possible uses.

#### 'From Point' Screen

The *From Point* input screen prompts the user to input a point number to use as a starting point for further calculations. Input types accepted:

1. An existing point number – The program ensures the point exists, and then displays the next screen.
2. A non-existing point number – The user may enter a point number that has not yet been stored in the database. An input form will open to allow the user to enter coordinates for the new point.
3. Two point numbers in the format “From..To” – Calculate a point inverse between two points in the job. The *From Point* input screen is re-displayed after this input type is processed. For example, input **1..2** to calculate the inverse from Point 1 to Point 2.
4. Three point numbers in the format “Start..End..Offset” – Calculate a point to line inverse by entering the baseline start and end points and the offset point. The *From Point* input screen is




re-displayed after this input type is processed. For example, input **1..2..3** to calculate the offset of Point 3 from the line defined by points 1 and 2.

5. Three point numbers in the format “BC+CC+EC” – Calculate a curve inverse, direction ‘right’, by entering the beginning of curve, curve center and end of curve points separated by the ‘+’ character. The *From Point* input screen is re-displayed after this input type is processed. For example, input **1+2+3** to inverse a curve connecting Point 1 and Point 3 in a clockwise direction with curve center (radius point) at Point 2.
6. Three point numbers in the format “BC-CC-EC” – Calculate a curve inverse, direction ‘left’, by entering the beginning of curve, curve center and end of curve points separated by the ‘-’ character. The *From Point* input screen is re-displayed after this input type is processed. For example, input **1-2-3** to inverse a curve connecting Point 1 and Point 3 in a counter clockwise direction with curve center (radius point) at Point 2.
7. **[F1] BROWS** – Opens the Point Browser to review points in the job and pick one from a list.
8. **[F2] CURVE** – Starts the *Curve Traverse* program.
9. **[F3] FP?■** – Toggles the *From Point* number suggestion setting. When the square is displayed after the “FP?”, the setting is enabled and the program will suggest a point number automatically, otherwise no suggestions are made.
10. **[F4] <TR>** or **<SS>** – Works in tandem with the **FP?** softkey to suggest point numbers by *TRAVERSE* or *SIDESHOT* methods. *TRAVERSE* always suggests the last saved point, while *SIDESHOT* keeps the point unchanged until changed by the user.
11. **[F5] CANCL** – Exits the *Point Traverse Standard* program, the same as pressing the **[ON]** key.
12. **[F6] OK** – Accepts the input provided, the same as pressing the **[ENTER]** key.
13. All other input is ignored or results in an error message.

### ‘Azimuth 1’ or ‘Bearing 1’ Screen

The *direction reference* setting determines whether *Azimuth* or *Bearing* is displayed. This screen prompts the user to input the azimuth or bearing to the new point from the *FROM POINT*. Input types accepted:

1. Azimuth or Bearing – The real number entered is interpreted based on the current *angle unit* and *direction reference* user settings and the next screen is displayed.




2. Any of the standard [directions](#) input options.
3. Any of the above input options followed by “++Offset” or “--Offset” – Define a parallel offset from the **FROM POINT**. The ‘++’ denotes an offset ‘right’ while ‘--’ denotes an offset ‘left’. For example, input **15.3025++5.5** to enter a parallel offset of 5.5 units to the ‘right’ of the **FROM POINT** and perpendicular to the entered azimuth **15°30'25"**.
4. Leave blank, no input – Signals that the azimuth or bearing to the new point is unknown, which leaves the possibility of a Distance-Azimuth, a Distance-Distance, or a Distance-Angle intersection.
5. **F1 B->A** or **A->B** – Converts the input between bearings and azimuths. The appearance and action of this softkey varies depending on your [direction reference](#) setting.
6. **F2 ±180°** – Flips the direction of the number in the command line by adding/subtracting 180 degrees (or 200 gons). **THIS OPTION IS ONLY AVAILABLE WHEN AZIMUTHS ARE SET AS THE DIRECTION REFERENCE.**
7. **F4 LAST** – Inserts the most recent azimuth or bearing input into the command line.
8. **F5 CANCL** – Cancels the traverse and returns the program to the **FROM POINT** screen.
9. **F6 OK** – Accepts the input as provided.

### ‘Distance 1’ Screen

This screen prompts the user to input the distance to the new point from the **FROM POINT**. Input types accepted:


1. A distance – The number entered is used as the distance and the next screen is displayed.
2. Any of the standard [distances](#) input options.
3. Leave blank, no input – Signals that the distance to the new point is unknown, which leaves the possibility of an Azimuth-Azimuth or an Azimuth-Distance intersection, provided that the **Azimuth 1** input was given.
4. **F1 F->M** or **M->F** – Converts the input between metric and imperial units. The appearance and action of this softkey varies depending on your [primary distance unit](#) setting.
5. **F2 xUSF** – Multiplies the input by the [user defined scale factor](#). **THIS CAN BE USED FOR SCALING VALUES GRID<>GROUND AS YOU GO, OR COULD BE AN ALTERNATIVE METHOD TO CONVERT BETWEEN UNITS.**
6. **F3 /USF** – Divides the input by the [user defined scale factor](#).
7. **F4 LAST** – Inserts the most recent distance input into the command line.



8. **F5 CANCL** – Cancels the traverse and returns the program to the **FROM POINT** screen.
9. **F6 OK** – Accepts the input as provided.


### 'TO Point' Screen

This screen accepts the point number of a second known point that an intersection connected **TO**. This screen appears when either the *Azimuth 1* or *Distance 1* inputs are unknown and left blank.




### 'Azimuth 2' or 'Bearing 2' Screen

This screen has two possible variations depending on whether *Azimuth 1* or *Distance 1* is known. In both cases the screen prompts the user to enter the azimuth or bearing from the new point that is being calculated **TO** the second known point. This screen accepts the same input types as the [Azimuth 1](#) screen.



With a known *Distance 1* input there exists a possibility to perform a Distance-Angle intersection. This option is available through the **F3 ANGLE** softkey. The included angle **TO** the second known point at a certain distance from the **FROM POINT** is required for this type of intersection.



### 'Distance 2' Screen

This screen prompts the user to enter the distance from the new point that is being calculated **TO** the second known point. This screen accepts the same input types as the [Distance 1](#) screen.

### STORE POINT Screen

The STORE POINT screen displays the coordinates of the solved point and prompts the user to enter a point number. The menu features a few point searching capabilities:

1. **[F1] LOW** – Inserts the lowest unused point number into the command line.
2. **[F2] NEXT** – Inserts the next lowest unused point number starting from the currently entered value.

A screen prompting to enter a point description will follow if the [description prompts](#) toggle is set. Alpha mode is automatically set when this screen becomes active and the menu labels display the Alpha characters. The **▼** cursor key opens the [codelist](#) to select a point description. When the [codelist translation](#) toggle is set, the user can enter any defined code in the codelist and the program will automatically look up the description and store the code's description.

The image contains two screenshots of the COGO+ software interface. The top screenshot shows the 'Distance 2' screen with a text input field containing 'Distance 2' and a menu bar with options F->M, <USF, >USF, LAST, CANCEL, and OK. The bottom screenshot shows the 'STORE POINT' screen with coordinates n: 50.819m, e: 41.783m, and z: 0.000m, followed by a 'Point Number' input field with '2' and a menu bar with options LOW, NEXT, CANCEL, and OK.

The image shows the 'STORE POINT' screen with a 'CODELIST' button. Below it, a 'Description' input field shows 'COGO' with a cursor. A codelist table is displayed with columns for letters A through F and rows for codes 1 through 6. The cell for COGO at row 1, column A is highlighted.

	A	B	C	D	E	F
1						
2						
3						
4						
5						
6						

## Sideshot Mode

**Point Traverse** *Sideshot* is a COGO application that accepts all input within a single input form with a few variations of possible input types.

### 'From Point' Field

This field requires an existing point number to use as the starting point, or station. Entering a point number that does not exist in the job will open an input form to allow the user to enter coordinates for the new point.

POINT TRAVERSE Sideshot	
From Point:	6
Backsight:	1
4 Ang Right ↗	74°25'00"
Hs Distance:	50.000m
Offset:	0.000m
4 Horizontal Angle	
EDIT CURVE SSHOT EXIT CANCEL TRAV	

### 'Backsight' Field

This field requires an existing point number to use as the backsight point. This field disappears when the horizontal angle field label is set to *Azimuth* or *Bearing* since it becomes unnecessary, but is required for an *Angle Right* or *Angle Left* calculation.

POINT TRAVERSE Sideshot	
From Point:	6
4 Azimuth ↗	74°25'00"
Hs Distance:	50.000m
Offset:	0.000m
4 Horizontal Angle	
EDIT CURVE SSHOT EXIT CANCEL TRAV	

### 'Angle Right' / 'Angle Left' / 'Azimuth' or 'Bearing' Field

The label for this field changes when the user toggles the input types for this field with the  and  cursor keys. This field requires a real number angle when *Angle Right* or *Angle Left* is selected. Input types accepted when *Azimuth* or *Bearing* is selected:

1. Azimuth or Bearing – The real number entered is interpreted based on the current [angle unit](#) and [direction reference](#) user settings.
2. Any of the standard [directions](#) input options.

### 'Hs Distance' Field

This field requires the distance to the new point from the **FROM POINT**. Input types accepted:

1. A distance – The number entered is used as the distance.
2. Any of the standard [distances](#) input options.

When the command line becomes active, i.e. a distance is being entered or edited, the softmenu will update to show more options:

1. **F1 F->M** or **M->F** – Converts the input between metric and imperial units. The appearance of this softkey varies depending on your [primary distance unit](#) setting.
2. **F2 xUSF** – Multiplies the input by the [user defined scale factor](#). THIS CAN BE USED FOR SCALING VALUES GRID<>GROUND AS YOU GO, OR COULD BE AN ALTERNATIVE METHOD TO CONVERT BETWEEN UNITS.
3. **F3 /USF** – Divides the input by the [user defined scale factor](#).

POINT TRAVERSE Sideshot	
From Point:	6
Backsight:	1
4 Ang Right ↗	74°25'00"
Hz Distance:	50.000m
Offset:	0.000m
50.000m	
F->M xUSF /USF [CANCL] [OK]	

### 'Offset' Field

This field accepts a perpendicular offset value from the line of direction. A positive offset is to the right while a negative offset is to the left. This field accepts the same types of inputs as the *Hz Distance* field.

### The Menu

The **Point Traverse Sideshot** input form menu:

1. **F1 EDIT** – Edits the currently selected field by copying the field's contents to the command line and activating the command line.
2. **F2 CURVE** – Starts the [Curve Traverse](#) program.
3. **F3** or **F6 SSHOT** – Takes the input provided and attempts to store the information as a sideshot. When successful, the [STORE POINT](#) screen is displayed to store the new point and the original **Point Traverse Sideshot** input form is re-displayed, unchanged.
4. **F4 <TR>** or **<SS>** – Toggles the location of the **TRAV** and **SSHOT** softkeys between **F3** and **F6**.
5. **F5 CANCL** – Exits the **Point Traverse Sideshot** program.
6. **F6** or **F3 TRAV** – Takes the input provided and attempts to store the information as a traverse point. When successful, the [STORE POINT](#) screen is displayed to store the new point and the original **Point Traverse Sideshot** input form is re-displayed, with the newly stored point in the *From Point* field, and the previous *FROM POINT* set as the *BACKSIGHT* point.


POINT TRAVERSE Sideshot	
From Point:	6
Backsight:	1
4 Ang Right ↗	74°25'00"
Hz Distance:	50.000m
Offset:	0.000m
4 Horizontal Angle	
EDIT CURVE SSHOT <TR> [CANCL] [TRAV]	

## Curve Traverse

The **Curve Traverse** program is accessible from the main screen of **Point Traverse Standard** and **Point Traverse Sideshow**. The program allows the user to enter a beginning of curve (BC) point and a radius point, then enter a known curve element and curve direction to solve the end of curve (EC) point.


### 'BC Point' Screen

This screen prompts the user to enter the beginning of curve point number. A point number is automatically suggested for this input, usually the previously stored point, which can be useful when calculating multiple points along the same arc. **F2** **SOLVE** opens the horizontal curve solver.



### 'Radial Point' Screen

This screen prompts the user to enter the radius point number. The radius point input is remembered for the next use until the user quits the **Curve Traverse** program.



### CURVE TRAVERSE Form

This input form accepts the known element of the curve and the curve direction.

The label for the first field changes when the user toggles the input types for this field with the **◀** and **▶** cursor keys. Available input options include the curve deflection angle, arc length, chord length or the tangent length.



The second field is a Right or Left option for the curve direction. Direction 'Right' is always clockwise, while 'Left' is counter clockwise.

The standard **STORE POINT** screen follows valid input to store the EC point. The **Curve Traverse** program continues until cancelled.

## 5.2 Inverse

**Inverse Points, Inverse Curve, Inverse Angle, Inverse Point to Line, Inverse Point to Curve and Inverse Point to Alignment** are available options for inverting with point coordinates in the current job database.

## Inverse Points

Enter the *From Point* and *To Point* to calculate the inverse information between any two points in the job database.

The results screen displays the azimuth/bearing, horizontal distance, slope distance, slope grade, and coordinate differences between the two points. The menu:

1. **F1 M<>F** – Toggles metric/imperial.

2. **F2 B<>A** – Toggles bearings/azimuths.

3. **F3 COORD** – Presents three options to solve coordinates between the two points. The options are by **Station/Offset**, by **Distance Interval**, or by **Equal Partitions**.

4. **F4 STACK** – Exports the direction, horizontal and slope distances to the stack.

5. **F5 LOOP** - Loops through the current job database inverting sets of two points in the order they were stored.

**INVERSE POINTS 1-2**

Azimuth: 39°25'37"

H2 Dist: 65.791m

SL Dist: 65.791m




Grade: 0.000 %

•North: 50.819m

•East: 41.783m

•Elev: 0.000m

**M<>F B<>A COORD STACK LOOP OK**



## Solve COORDinates

Pick this option to calculate coordinates between the two points. **Station/Offset** accepts any station and offset to calculate the coordinate of a point, **Distance Interval** will store points at the given distance interval, and **Equal Partitions** will divide the line into equal partitions, storing a point at each calculated partition.

### Station/Offset

The first input form requires the selection of a *Known Station*, either the beginning (*From Point*) or the end (*To Point*) of the straight line, and a *Station* input at that point to calculate coordinates at any station and offset between the two points.



The second input form accepts a *Station* and a perpendicular *Offset* from the line. A positive offset is to the right while a negative offset is to the left. The 3D coordinates of the calculated point are immediately displayed on the screen. The menu:

1. **F4 Sta?** – Select a position to jump to on the line; beginning, mid-point or end of the line.

Sets the *Station* field value to the selected station and sets the *Offset* field to zero.

2. **F6 STORE** – Stores the calculated coordinates as a point in the job database.

NOTE: Stations are displayed with a “<” character preceding the station when the station is less than the station of the beginning of the line, and displayed with a “>” character preceding the station when the station is greater than the end of the line. Coordinates can be calculated for any station along the projection of the defined line.



### Distance Interval

The first input screen will display the length of the line and accept a distance interval value. Points will be created every specified distance starting at the *From Point* of the line until the remainder to the *To Point* of the line is less than or equal to the distance interval specified.

The second input screen prompts for a Starting Point Number to be used for storing the points that will be calculated. Unused point number will be assigned to the positions starting at the specified point number. Point coordinates are calculated in three dimensions between the *From Point* and *To Point*.

<b>DIVIDE By Distance</b>					
Length of Line:					
65.791m					
Distance Interval					
10♦					
F->H	✓USF	✗USF	LAST	CANCL	OK

<b>DIVIDE By Distance</b>				
Starting Point #				
17♦				
LOW	NEXT		CANCL	OK

### Equal Partitions

The first input screen will display the length of the line and accept the number of partitions to divide the line into. Points will be created at the calculated interval so that the specified number of equal partitions will be created between the *From Point* and *To Point*.

<b>EQUAL Partitions</b>				
Length of Line:				
65.791m				
Number of Partitions				
10♦				
			CANCL	OK

The second input screen prompts for a Starting Point Number to be used for storing the points that will be calculated. Unused point number will be assigned to the positions starting at the specified point number. Point coordinates are calculated in three dimensions between the *From Point* and *To Point*.

<b>EQUAL Partitions</b>				
Starting Point #				
17♦				
LOW	NEXT		CANCL	OK

## Inverse Curve

Enter the *Beginning of Curve Point*, the *Radius Point* and the *End of Curve Point*, and choose the *Curve Direction* to calculate the curve information.

The results screen displays the radius, deflection angle, arc length, chord length, tangent length, mid-ordinate length and the external length. Use the  $\downarrow$  and  $\uparrow$  keys to toggle between the first and second page of the results. Page 2 displays the sector, segment and fillet areas of the curve. The menu:

1. **F1 M<>F** – Toggles metric/imperial.
2. **F2 COORD** – Presents three options to solve coordinates between the end points along the curve. The options are by **Station/Offset**, by **Distance Interval**, or by **Equal Partitions**.
3. **F3 EXPRT** – Exports the results to the stack, to an ASCII file, or copy to the clipboard.

## Solve COORDinates

Pick this option to calculate coordinates between the end points of the curve. **Station/Offset** accepts any station and offset to calculate the coordinates of a point, **Distance Interval** will store points at the given distance interval, and **Equal Partitions** will divide the curve into equal partitions, storing a point at each calculated partition.

<b>INVERSE CURVE</b>	
Beg Curve Point:	15
Radius Point:	14
End Curve Point:	13
Curve Direction:	Right <b>↓↑</b>
Curve Direction	
<b>CHOOS</b>	<b>CANCL</b>
<b>OK</b>	

<b>INVERSE CURVE 15+14+13 1/2</b>		
Radius:	21.000m	
Defl. a:	26°49'02"	
Arc:	9.829m	
Chord:	9.740m	
Tangent:	5.006m	
Mid-Ord:	0.572m	
External:	0.588m	
Chord Az:	201°49'14"	
<b>M&lt;&gt;F</b>	<b>COORD</b>	<b>EXPRT</b>
<b>CANCL</b>		<b>OK</b>

<b>INVERSE CURVE 15+14+13 1/2</b>	
Radius:	21.000m
Defl:	<b>CALCULATE COORDINATES</b>
Arc:	<b>1. Station/Offs...</b>
Chor:	<b>2. Distance Int...</b>
Tang:	<b>3. Equal Partit...</b>
Mid-	
External:	0.588m
Chord Az:	201°49'14"
<b>CANCL</b>	<b>OK</b>

## Station/Offset

The first input form requires the selection of a *Known Station* (BC, PI or EC) on the curve, and a *Station* input at that point to calculate coordinates at any station and offset along the curve.

The second input form accepts a *Station* and a perpendicular *Offset* from the curve. A positive offset is to the right while a negative offset is to the left. The coordinates of the point are immediately displayed on the screen. The menu:

1. **F4 Sta?** – Select a position to jump to on the curve; BC, PI, EC, mid-point of curve, or the Radius Point. Sets the *Station* field to the selected station and sets the *Offset* field to zero. **NOTE: THE PI STATION IS NOT ON THE CURVE.**
2. **F5 STORE** – Stores the calculated coordinates as a point in the job database.

## Distance Interval

The first input screen will display the length of the curve and accept a distance interval value. Points will be created every specified distance starting at the *Beginning of Curve Point* until the remainder to the *End of Curve Point* is less than or equal to the distance interval specified.

The second input screen prompts for a Starting Point Number to be used for storing the points that will be calculated. Unused point number will be assigned to the positions starting at the specified point number. Point coordinates are calculated in three dimensions between the *Beginning of Curve Point* and *End of Curve Point*.

ENTER KNOWN STATION	
Known Station: BC	
Station: 0+00.000	
Choose Known Station Point	
CH005	CANCL OK

SOLVE COORDINATES			
Station: 0+05.000			
Offset: -3.000m			
Northing: 2998.0961m			
Easting: 2974.1820m			
Enter Station to Solve			
EDIT	RESET Sta?	CANCL	STORE

DIVIDE By Distance					
Length of Curve:					
9.829m					
Distance Interval.....					
34					
F->H	BSUF	/USF	LAST	CANCL	OK

DIVIDE By Distance				
Starting Point #				
174				
LOW	NEXT		CANCL	OK

## Equal Partitions

The first input screen will display the length of the curve and accept the number of partitions to divide the curve into. Points will be created at the calculated interval so that the specified number of equal partitions will be created between the *Beginning of Curve Point* and *End of Curve Point*.

<b>EQUAL Partitions</b>	
Length of Curve:	
9.829m	
Number of Partitions	
3*	
CANCL	OK

The second input screen prompts for a Starting Point Number to be used for storing the points that will be calculated. Unused point number will be assigned to the positions starting at the specified point number. Point coordinates are calculated in three dimensions between the *Beginning of Curve Point* and *End of Curve Point*.

<b>EQUAL Partitions</b>	
Starting Point #	
17*	
LOW	NEXT
CANCL	OK

## Inverse Angle

Enter the *Backsight Point*, the *Occupy Point* and the *Foresight Point* to calculate the included angle. The *Backsight Point* is always from clockwise resulting in an “angle right” calculation.

INVERSE ANGLE			
Backsight Point:	12		
Occupy Point:	11		
Foresight Point:	10		
Backsight Point (Clockwise)			
EDIT	RESET	CANCL	OK

The results screen displays the turned angle and its complementary angle as well as the distances to the backsight and foresight points from the occupy point.

Use **F1 M<>F** to convert the distance results between metric and imperial units.

INVERSE ANGLE 12-11-10			
Angle:	118°38'29"		
Explem:	241°21'31"		
To BS:	5.439m		
To FS:	20.958m		
EDIT	RESET	CANCL	OK

## Inverse Point to Line

Enter two points, *Baseline P1* and *Baseline P2*, to define a baseline and an *Offset Point* to calculate the perpendicular offset of the point to the line.

The results screen displays the offset from the baseline, Station 1 from *Baseline P1* to a point along the baseline that is perpendicular to the offset point, Station 2 to the same point from *Baseline P2*, the cut/fill to the baseline and the length, direction and the grade of the baseline.

The menu:

1. **F1 M<>F** – Toggles metric/imperial.
2. **F2 B<>A** – Toggles bearings/azimuths.
3. **F3 STORE** – Stores the coordinates of the point along the baseline perpendicular to the offset point as a point in the job database.

INVERSE POINT TO LINE			
Baseline P1:	50		
Baseline P2:	51		
Offset Point:	55		
First point on baseline			
EDIT	RESET	CANCL	OK

INVERSE POINT TO LINE			
Offset:	9.204m		
Sta 1:	7.828m		
Sta 2:	19.496m		
Cut:	-0.246m		
Length:	27.324m		
Azimuth:	90°00'00"		
Grade:	1.069 %		
EDIT	B<>A	STORE	OK

## Inverse Point to Curve

Enter a *Beginning of Curve Point*, a *Radius Point* and a *End of Curve Point*, choose a *Curve Direction*, and enter a *Offset Point* to calculate the perpendicular offset of the point to the curve.

The results screen displays the offset from the curve, Station 1 from the *Beginning of Curve* to a point along the curve that is perpendicular to the offset point, Station 2 to the same point from the *End of Curve*, the cut/fill to the curve, and the radius, length and grade of the curve. The menu:

1. **F1 M<>F** – Toggles metric/imperial.
2. **F2 STORE** – Stores the coordinates of the point along the curve perpendicular to the offset point as a point in the job database.

INVERSE POINT TO CURVE			
Begin Point:	15		
Radius Point:	14		
End Point:	13		
Curve Direc:	Right		
Offset Point:	55		
Beginning of Curve Point			
EDIT	RESET	CANCL	OK

INVERSE POINT TO CURVE		
Offset:	-8.583m	
Sta 1:	7.522m	
Sta 2:	2.307m	
Cut:	-0.096m	
Radius:	21.000m	
Length:	9.829m	
Grade:	-10.184 %	
SMOKE	STORE	OK



## Inverse Point to Alignment

Choose an [alignment](#) from the list of available alignments to inverse a point to the alignment and determine the station, offset and cut/fill of the point in relation to the alignment design.

Enter a point number to inverse to the selected alignment, and specify a maximum offset from centerline. Optionally specify a vertical offset constant from the alignment design, and choose whether elevation values are calculated to the cross section template or to the centerline of the alignment.


The maximum offset value is used to eliminate erroneous inverse results that may occur when alignments have significant geometry changes which could in turn provide offsets that are valid but not for the desired station.

The result includes the point number entered, the calculated station, offset and cut/fill. Use  **M>F** to toggle the offset and cut/fill between metric/imperial.



## 5.3 Intersections

The **Intersections** program exclusively handles all types of intersections from a single input form. The words "Bearing" and "Azimuth" are interchangeable for naming the intersection types. In the diagram shown, the '1<sup>st</sup> Point' and '2<sup>nd</sup> Point' points are always known points and the 'New Point' point can be calculated when **BEARING1** or **DISTANCE1** and **BEARING2** or **DISTANCE2** is known.



### '1<sup>st</sup> Point' and '2<sup>nd</sup> Point' Fields

Both of these fields require an existing point number.

### 'Azimuth' or 'Bearing' / 'Distance' Fields

The labels for these fields change when the user toggles the input types for these fields with the **◀** and **▶** cursor keys. The label indicates how the input will be processed:

1. Azimuth/Bearing input is accepted using any of the standard [directions](#) input options.
2. Distance input is accepted using any of the standard [distances](#) input options.

INTERSECTIONS			
1st Point:	10		
4 Azimuth	► 0°00'00"		
Offset:	0.000m		
2nd Point:	11		
4 Azimuth	► 0°00'00"		
Offset:	0.000m		
1st Point			
<b>EDIT</b>	<b>RESET</b>	<b>CANCL</b>	<b>OK</b>

### 'Offset' Fields

These fields are only visible when the corresponding **AZIMUTH** or **BEARING** is the selected known component. Enter offsets using any of the standard [distances](#) input options.

**NOTE: THE DIRECTIONS OF BEARING1 AND BEARING2 MAY BE FLIPPED 180° WITHOUT CONSEQUENCE, HOWEVER IF YOU ENTER ANY OFFSETS, THESE OFFSETS WILL ALWAYS BE RELATIVE TO YOUR DIRECTION ENTERED (LEFT OR RIGHT).**

### **Bearing-Bearing**

A bearing-bearing intersection can be solved when **BEARING1** and **BEARING2** are known. Offsets may be entered for both azimuth/bearing inputs. Entering offsets makes it possible to create an offset intersection, for example.

INTERSECTIONS			
1st Point:	10		
4 Azimuth	► 45°47'00"		
Offset:	0.000m		
2nd Point:	11		
4 Azimuth	► 145°43'00"		
Offset:	0.000m		
Offset 2			
<b>EDIT</b>	<b>RESET</b>	<b>CANCL</b>	<b>OK</b>

## Bearing-Distance

A bearing-distance intersection can be solved when **BEARING1** and **DISTANCE2** are known. This type of intersection usually has two possible solutions. The user is prompted to choose which of the two solutions is desired by selecting one of the two possible **DISTANCE1** solutions. A “No Solution” error indicates that the intersection is not possible with the data provided.

INTERSECTIONS	
1st Point:	10
4 Azimuth	45°47'00"
Offset:	0.000m
2nd Point:	11
4 Distance	42.243m
1st Point	
EDIT	RESET
CANCEL	OK

## Distance-Bearing

A distance-bearing intersection can be solved when **DISTANCE1** and **BEARING2** are known. This type of intersection is similar to a bearing-distance intersection but started from the opposite direction, and usually also has two possible solutions. The user is prompted to choose which of the two solutions is desired by selecting one of the two possible Bearing1 solutions.

INTERSECTIONS	
1st Point:	10
4 Distance	41.019m
2nd Point:	11
4 Azimuth	225°47'00"
Offset:	0.000m
Offset 2	
EDIT	RESET
CANCEL	OK

## Distance-Distance

A distance-distance intersection can be solved when **DISTANCE1** and **DISTANCE2** are known. This type of intersection usually has two possible solutions. The user is prompted to choose which of the two solutions is desired by selecting one of the two possible **BEARING1** solutions.

INTERSECTIONS	
1st Point:	10
4 Distance	41.019m
2nd Point:	11
4 Distance	42.243m
1st Point	
EDIT	RESET
CANCEL	OK

## 5.4 Area by Points


The **Area by Points** program calculates the area of a polygon when the points along the perimeter of the polygon are entered in sequence. The polygon can consist of straight segments and curves.

To enter straight segments:

1. Enter individual points separated by spaces. For example, **1 2 3 4 5 6**.
2. Enter a range of points in sequence and in numerical ascending order. For example, **1..6**.
3. Enter any combination of the above. For example, **1 3 9..15 18 20..29 33**.

To enter curves:

1. Curve 'Right' – Enter points separated by the '+' character so that the curve is defined by BC+CC+EC. For example, **1+2+3**.
2. Curve 'Left' – Enter points separated by the '-' character so that the curve is defined by BC-CC-EC. For example, **1-2-3**.
3. Compound curves and reverse curves – Enter each curve component separately so that each curve component is its own block of points, BC+CC+EC or BC-CC-EC, and each block is separated by a space. For example, **1+2+3 3-4-5** or **1+2+3 3+4+5**, etc.




**NOTE: AN ERROR OCCURS WHEN THE POINTS PROVIDED AS CURVE POINTS DO NOT ACTUALLY DEFINE A CURVE, I.E. THE RADIUS DIFFERS BY MORE THAN THE radius tolerance SETTING.**

Any mix of straight segments and curves is accepted. For example, an area with straight segments and a curve could be **10 11 12 13-14-15** which could also be entered as **10..12 13-14-15**.

The menu on the input screen:


1. **F1 BROWSE** - Opens the point browser to select/review points.
2. **F2 ALL** - Use all points in the current job, the points will be used in the sequence they were created. **NOTE: BE CAREFUL WITH THIS OPTION, THIS OPTION COULD PROVIDE RESULTS YOU DO NOT EXPECT OR IT COULD TAKE SOME TIME TO CALCULATE WHEN SEVERAL HUNDRED POINTS EXIST.**
3. **F3 HELP** - Displays a summary of how input is accepted.
4. **F4 SUB** - Subdivide a pre-determined area.

The area (square units and hectares/acres) and perimeter are displayed following a valid input. The program automatically determines the direction (clockwise or counter clockwise) the points were entered. The primary distance unit affects the results displayed.




The menu on the results screen:

1. **F1 M<>F** - Toggles metric/imperial.
2. **F2 PLOT** - Draws the area polygon on the screen.
3. **F3 EXPRT** - Writes a DXF file of the polygon linework to save to the SD card **COGOPLUS\ASCII** directory or to the HOME directory on the calculator. DXF files can be opened with a CAD program.




## Area Subdivisions

COGO+ Pro Version 3.57 introduced two BETA editions of area subdivision programs. Coordinates of the missing point(s) are calculated to complete the fixed-area polygon.



### Sliding Bearing/Azimuth

Calculate a specified area by sliding a line of fixed bearing/azimuth. For the diagram on the right, assume the known coordinates as listed and the fixed azimuth line to be  $6^{\circ}10'35''$  with a desired area of  $100m^2$ . The program will calculate the coordinates for highlighted points 6 and 7 shown.



First, enter the points that define the fixed boundaries, in this example those points are 2, 3 and 4.

Next, enter the directions from the first and from the last point that you entered for the fixed points. Use any of the standard [directions](#) input options.

<b>SLIDING AZIMUTH SUBDIVIDE</b>			
Enter the points that define the fixed boundaries			
Fixed Points .....			
2	3	4*	
BROWNS		CANCL	OK

Enter the first direction			
Azimuth from Pt. 2 .....			
2..1*			
±180°		CANCL	OK

Enter the second direction			
Azimuth from Pt. 4 .....			
4..5*			
±180°		CANCL	OK

Next, enter the sliding azimuth/bearing followed by the desired area.

Enter the sliding Azimuth			
Sliding Azimuth .....			
6.1035*			
±180°		CANCL	OK

Enter the desired area in square units			
Desired Area .....			
100*			
		CANCL	OK

The solution for each point is presented on the standard STORE POINT screen.

<b>STORE POINT</b>			
n: 100.298m			
E: 97.017m			
z: 0.000m			
Point Number .....			
6*			
LOW	NEXT	CANCL	OK

<b>STORE POINT</b>			
n: 89.687m			
E: 95.869m			
z: 0.000m			
Point Number .....			
7*			
LOW	NEXT	CANCL	OK


When both points are stored in the job database a message appears on the screen "New Area String copied to Clipboard...". This allows the user to paste the clipboard contents into the Area by Points program to confirm the solution.

Use  followed by PASTE to paste the clipboard contents into the Area by Points input screen.

The solution and plot should be as shown below.


AREA BY POINTS	
Area:	100.000m <sup>2</sup>
	0.010 ha
Perim:	38.647m
<input type="button" value="ECHO"/> <input type="button" value="PLOT"/> <input type="button" value="EXPT"/> <span style="float: right;"><input type="button" value="OK"/></span>	

AREA BY POINTS	
Points .....	
6 2 3 4 7*	
<input type="button" value="BROW"/> <input type="button" value="ALL"/> <input type="button" value="HELP"/> <input type="button" value="SUB"/> <input type="button" value="CANCL"/> <input type="button" value="OK"/>	



### Hinge Point

Calculate a specified area by swinging a line from a hinge point into another line of fixed bearing/azimuth. For the diagram on the right, assume the known coordinates as listed and the direction from Point 5 to be parallel to the line 4-3 with a desired area of 180m<sup>2</sup>. The program will calculate the coordinates for highlighted point 6 shown.



First, enter the points that define the fixed boundaries, starting with the hinge point. In this example those points are 1, 2, 3, 4 and 5.

HINGE POINT SUBDIVIDE	
Enter the points that define the Fixed boundaries, starting with the hinge point	
Fixed Points .....	
1 2 3 4 5*	
<input type="button" value="BROW"/> <input type="button" value="CANCL"/> <input type="button" value="OK"/>	

Next, enter the direction from the last fixed point followed by the desired area. Use any of the standard [directions](#) input options.

Enter the direction

Azimuth from Pt. 5.....

4..3<sup>♦</sup>

Enter the desired area in square units

Desired Area.....

180<sup>♦</sup>

The solution for the point is presented on the standard STORE POINT screen.

When the point is stored in the job database a message appears on the screen "New Area String copied to Clipboard...". This allows the user to paste the clipboard contents into the Area by Points program to check to confirm the solution.

Use  followed by [PASTE](#) to paste the clipboard contents into the Area by Points input screen.

STORE POINT

N: 18.940m  
E: 11.662m  
Z: 0.000m

Point Number.....

6<sup>♦</sup>

AREA BY POINTS


Points.....

1 2 3 4 5 6<sup>♦</sup>

The solution and plot should be as shown below.

AREA BY POINTS


Area: 180.000m<sup>2</sup>  
0.018 ha  
Perim: 64.632m



## 5.5 Fit Points

The **Fit Points** program consists of:

1. Best fit points to a straight line, linear regression.
2. Best fit points to a curve, similar to linear regression but fits points to a circular curve.
3. Solve the position of a lost corner using the **Double Proportionate Method**.
4. Solve the position of a lost corner using the **Irregular Boundary Adjustment Method**.
5. Solve the positions of lost angle points using the **Grant Boundary Adjustment Method**.



### Best Fit Line



Enter a series of points to compute the least squares straight line that best fits the points. Enter point numbers using any of the [point numbers](#) input options.

An un-weighted linear regression method that minimizes BOTH X and Y residuals simultaneously is used to calculate the line.

The direction and Y-Intercept of the line, the correlation coefficient (a value between -1 and 1), and the point offsets standard deviation are computed and displayed.

The menu:

1. **M** – Toggles metric/imperial.
2. **B** – Toggles bearings/azimuths.
3. **INFO** – Displays the perpendicular offsets to the line for each point used in the computation.
4. **BEST** or **FIX** – The menu label indicates whether the calculation represents a best-fit line or a line with a fixed direction. It is possible to enter a direction for the line that



differs from the best-fit direction and recalculate with the fixed parameter.

5. **F5 CANCL** – Return to the points input screen without adjusting the points.
6. **F6 ADJU** – Proceed with adjusting the points.

Choosing to apply the solution will either shift the points to fall on the line, which overwrites the existing points, or calculate new points re-numbered with an additive point number. The [adjusted points](#) setting controls the behaviour of overwrite/re-number.

Points are always shifted perpendicular to the best-fit line to minimize the shift.

## Best Fit Curve

The main purpose of this program is to calculate the radius and the coordinates of the radius point of the least squares circle that best fits a series of points.


When providing points along one or both tangents, the program will also solve the BC and/or EC point coordinates.

In the main input form, enter a series of points along the curve to compute the circle that best fits the points.

Enter point numbers using any of the [point numbers](#) input options. The menu:

1. **F1 BROWS** - Opens the point browser to select/review points.
2. **F2 POT** - Toggle “Points On Tangents” input option. When enabled, the program will prompt for points on the back and forward tangent.

When the POT toggle is set, the program will also ask the user to choose the curve direction Right/Left.



**BEST FIT CURVE**

**Curve Points**.....

1 2 3 4\*

**BROWS** **POT** **CANCL** **OK**

Enter a point on the  
BACK Tangent  
Leave blank if none

**Tangent In Point**.....

6\*

**BROWS** **CANCL** **OK**

The first page of the curve solution displays the computed radius, the radius standard deviation, the coordinates of the radius point, and if applicable, the azimuths/bearings of the back and forward tangents.

The second page of the curve solution displays the coordinates of the BC and EC points if possible to solve with the input provided. **THIS PAGE IS NOT APPLICABLE WHEN THE POT TOGGLE IS NOT SET.**

The third page of the curve solution displays the curve elements: radius, deflection angle, arc, chord, tangent, mid-ordinate and external values. **THIS PAGE IS ONLY DISPLAYED WHEN BOTH POT INPUTS ARE PROVIDED.** The menu:

1. **F1** **STORE** – Stores the computed radius point coordinates as a point in the job database, or when possible to store BC and/or EC points, will ask the user to choose which point to store.
2. **F2** **M<>F** – Toggles metric/imperial.
3. **F3** **INFO** – Displays the radial offsets to the curve for each point used in the computation.
4. **F4** **BEST** or **FIX** – The menu label indicates whether the calculation represents a best-fit radius or a curve with a fixed radius. It is possible to enter a radius for the curve that differs from the best-fit radius and recalculate a new least squares circle with the fixed parameter.
5. **F5** **CANCL** – Return to the points input screen without adjusting the points.
6. **F6** **ADJU** – Proceed with adjusting the points.

Choosing to apply the solution will either shift the points to fall on the curve, which overwrites the existing points, or calculate new points re-numbered with an additive point number. The adjusted points setting controls the behaviour of overwrite/re-number.

Points are always shifted radially to the best-fit curve to minimize the shift.

CURVE SOLUTION		1/3 ▲▼
Radius:	3209.766m	
-StdDev:	0.023m	
North-0:	4053.9923m	
East-0:	5587.3746m	
Az In:	105°14'32"	
Az Out:	163°00'36"	
<input type="button" value="STORE"/> <input type="button" value="M&lt;&gt;F"/> <input type="button" value="INFO"/> <input type="button" value="BEST"/> <input type="button" value="CANCL"/> <input type="button" value="ADJU"/>		

CURVE SOLUTION		3/3 ▲▼
Radius:	3209.766m	
Defl. a:	57°46'04"	
Arc:	3236.209m	
Chord:	3100.868m	
Tangent:	1770.710m	
Mid-Ord:	399.294m	
External:	456.023m	
<input type="button" value="STORE"/> <input type="button" value="M&lt;&gt;F"/> <input type="button" value="INFO"/> <input type="button" value="BEST"/> <input type="button" value="CANCL"/> <input type="button" value="ADJU"/>		

POINT OFFSETS FROM CURVE		
1	0.009m	
2	-0.026m	
3	0.028m	
4	-0.010m	
<input type="button" value="M&lt;&gt;F"/> <input type="button" value="OK"/>		

## Double Proportion

"The term 'double proportionate measurement' is applied to a new measurement made between four known corners, two each on intersecting meridional and latitudinal lines, for the purpose of relating the cardinal equivalent intersection to both." (Page 166, BLM Manual of Surveying Instructions 2009).

The **Double Proportion** program solves this type of problem by accepting point numbers for the four known corners, and the record measurements to the lost corner.

The first input form requires existing point numbers of the corners to the north, east, south and west of the lost corner.

The second input form requires the **record** bearings and distances to the known corners west and east of the lost corner. When entering or editing a distance the menu offers the following functions:

1. **F1 F->M** or **M->F** – Converts the input between metric and imperial units. The appearance of this softkey varies depending on your [primary distance unit](#) setting.
2. **F2 xUSF** – Multiplies the input by the [user defined scale factor](#).
3. **F3 /USF** – Divides the input by the [user defined scale factor](#).

The third input form requires the **record** bearings and distances to the known corners north and south of the lost corner.

Following input, the coordinates of the lost corner are calculated and the point may be stored to the job database.

DOUBLE PROPORTION			
Point N: 1	N		
Point E: 2			
Point S: 3	W		
Point W: 4	E		
Enter Point North			
EDIT	RESET	CANCL	OK

DOUBLE PROPORTION			
Bg 1: N89°52'00"W	*		
Di 1: 2638.680ft	-----		
Bg 2: N89°37'00"W	*-1--2*		
Di 2: 2640.000ft	*		
Enter Record Bearing 1			
EDIT	RESET	CANCL	OK

DOUBLE PROPORTION			
Bg 3: N0°02'00"E	*		
Di 3: 5229.840ft	3		
Bg 4: N0°02'00"E	*-----4-----*		
Di 4: 2640.000ft	4		
Enter Record Bearing 3			
EDIT	RESET	CANCL	OK

## Irregular Boundary Adjustment

Irregular boundaries are the result of boundaries surveyed from opposite directions, or piecemeal surveys where resulting boundaries are not straight lines. "In order to restore one or more lost corners or angle points on such irregular exterior, a retracement between the nearest known corners is made on the record courses and distances to ascertain the direction and length of the closing distance. A position is calculated for each lost corner or angle point at the record position."




(Page 174, BLM Manual of Surveying Instructions 2009) A combination of single proportion and compass rule is then used to re-establish the lost corner. The direction (East-West or North-South) determines how the adjustment is performed.

The **Irregular Boundary** program prompts for the direction of the line, and then the first input form requires the point numbers for the surveyed points (W + E, or N + S).

The second input form requires the **record** dimensions to the corners on either side of the lost corner. When entering or editing a distance the menu offers the following functions:

1. **F1 F->M** or **N->F** – Converts the input between metric and imperial units. The appearance of this softkey varies depending on your primary distance unit setting.
2. **F2 xUSF** – Multiplies the input by the user defined scale factor.
3. **F3 /USF** – Divides the input by the user defined scale factor.

Following input, the coordinates of the lost corner are calculated and the point may be stored to the job database.



## Grant Boundary Adjustment

*"In many of the States there are irregular grant and reservation boundaries that were established prior to the public rectangular surveys. In these cases, the township and section lines are regarded as the closing lines. The grant boundary field notes may call for natural objects, but these are often supplemented by metes-and-bounds descriptions. The natural calls are ordinarily given precedence then the existent angle points of the metes-and-bounds survey. The lost angle points are then restored by uniformly orienting the record courses to the left or right and adjusting the lengths of the lines on a constant ration."* (Page 176, BLM Manual of Surveying Instructions 2009)

The **Grant Boundary** program requires a series of points that define the grant boundary, starting with a known (found) point followed by calculated points using **record** dimensions. The first input screen asks for these points. The second input screen asks for a *Closing Point*, which is a found original point representing the last calculated point that was entered. The spatial difference between the closing point and the last calculated point determines the adjustment parameters.

The calculated rotation and scale are displayed on the results screen. The menu:

1. **[F1] CW** or **CCW** – Toggles the rotation displayed as being clockwise or counter-clockwise.
2. **[F5] CANCL** – Cancel the adjustment and return to the input screen.
3. **[F6] ADJU** - Adjusts the record points. The adjustment will either update the existing point coordinates, which overwrites the existing points, or calculate new points re-numbered with an additive point number. The adjusted points setting controls the behaviour of overwrite/re-number.

